

SINGLE AND STACK DRYERS | Caldwell & Gregory

1 CLEAN LINT FILTER BEFORE EACH CYCLE




2 LOAD DRYER 1 WASH = 1 DRY



- NO FOOTWEAR IN THE DRYER
- DO NOT OVERLOAD MACHINES
- DO NOT SIT ON MACHINES
- DO NOT PUT COMFORTERS IN THE MACHINES

3 SELECT TEMPERATURE Please reference your fabric labels.



4 INSERT CARD OR CASH If required.

5 PUSH START BUTTON



SECADORAS SENCILLAS Y DOBLES | Caldwell & Gregory

1 LIMPIE EL FILTRO DE LA PELUZA



2 CARGE LA SECADORA 1 LAVADA = 1 SECADA



- ¡NO ZAPATILLAS DEPORTIVAS EN LA SECADORA!
- ¡NO SOBRECARGE LA MÁQUINA!
- ¡NO SE SIENTE EN LA MÁQUINA!
- ¡NO PONGA COLCHONES GRANDES EN LA MÁQUINA!

3 SELECCIONE LA TEMPERATURA

Por favor lea la etiqueta de la ropa.

4 INTRODUZCA EL DINERO O TARJETA

Si es requerido.

5 PRESIONE EL BOTÓN DE "START"

